

RightWON IEC 61850 Protocol Manual V1.5

Document No. RWM002030-MA-en © 2013 Vizimax Inc. All rights reserved.





Copyright

© Copyright Vizimax Inc., 2013. All rights reserved.

The information contained in this document is the proprietary and/or confidential information of Vizimax, Inc. ("Vizimax") and is subject to all relevant laws protecting intellectual property and confidential information, as well as to the terms of any specific agreement protecting Vizimax's rights in such information. Neither this document nor the information contained herein may be published, reproduced, transmitted or disclosed in whole or in part by any means for any purpose without the express, prior, written authorization of Vizimax. In addition, any use of this document or the information contained herein for any purposes other than those for which it was disclosed is strictly forbidden.

Vizimax may have patents or pending patents applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. The furnishing of this document does not constitute a license to these patents, trademarks, copyrights, or other intellectual property.

Document Disclaimer

Vizimax believes the information in this document to be accurate at the time of publication of the document. However, this document may contain errors or omissions. Vizimax makes no warranties regarding this document or its content. Vizimax is not responsible for any loss, liability, or damages of any kind arising from or related to this document or the information contained in it. In addition, this document or the information it contains cannot be regarded as binding on Vizimax, or used or retained against Vizimax. Information contained herein may be periodically updated or modified without notice in subsequent editions. If you encounter an error in this document, please contact Vizimax.

Any representations or statements in this document concerning Vizimax products are for informational purposes only and do not constitute warranties, either express or implied, regarding such products. Vizimax's standard limited warranty, stated in its sales contract or order confirmation form, is the only warranty offered by Vizimax in relation to the products.

All specifications and designs are subject to change without prior notice. Vizimax reserves the right, at its sole discretion, to modify or replace any part of this document. It is your responsibility to periodically check whether changes to this document are available.

Warranty Disclaimer

Vizimax and its suppliers and licensors hereby disclaim all warranties of any kind, express or implied, including, without limitation, the warranties of merchantability, fitness for a particular purpose and non-infringement. Neither Vizimax nor its suppliers and licensors make any warranty that Vizimax products will be error-free, or that access to remote units and their connected equipment will be continuous or uninterrupted.

Limitation of Liability

Vizimax products are programmable devices which can be modified by anyone who has been given authorization to access the product and log onto its configuration software. Vizimax cannot oversee modifications to the configuration of Vizimax products unless a prior service agreement has been made between all parties involved. Vizimax does not have any control over who is given permission to access Vizimax products. Vizimax cannot therefore be held responsible for the configuration, automatisms and actions that are programmed into any Vizimax product once it has been delivered to the purchaser or third party. Likewise, Vizimax is not responsible for the particular use of Vizimax products in industrial, commercial or other applications, nor is it liable for any harmful effects arising from such use.

You are responsible for taking the necessary precautions to protect yourself, your computer networks and all connected equipment from any harmful or destructive actions that may arise due to incorrect programming of Vizimax products, or any voluntary or involuntary actions on the part of a user. Vizimax disclaims any responsibility for any harm resulting from the use of the RightWON.

In no event will Vizimax, or its suppliers or licensors, be liable with respect to any subject matter under any contract, negligence, strict liability or other legal or equitable theory for: (i) any special, incidental or consequential damages; (ii) the cost of procurement or substitute products or services; (iii) interruption of service, or the loss or corruption of data.

Vizimax, its contractors, licensors, and their respective directors, officers, employees and agents, are hereby indemnified from any and all claims and expenses, including attorneys' fees, arising out of your use or misuse of Vizimax products. Vizimax shall have no liability for any damage, injury, failure or delay due to matters beyond the reasonable control of Vizimax.

The foregoing shall not apply to the extent prohibited by applicable law.

Trademarks

Vizimax, the Vizimax logo, RightWON, WiseWON, SynchroTeq, SynchroTeq+ and the RightWON icons are trademarks or registered trademarks of Vizimax, Inc. in Canada, the United States and other jurisdictions. All other trademarks, registered trademarks and service marks are the property of their respective owners.

Your use of Vizimax products grants you no right or license to reproduce or otherwise use any Vizimax or third-party trademarks.

Vizimax is a licensed user of the following service marks:





Introduction		1
1.1. About the IEC 61850 protocol		1
1.1.1. SCL file description 1.1.2. Identification of data object	ts and data attributes	1 3
1.1.3. Description of control mode	els for operating the equipment	4 1
1.1.5. Support of the IEC 61400-2	25 standard	4
1.2. Document scope		5
1.2.1. Other documents		5
1.3. Document conventions		5
1.4. Safety precautions		5
1.4.1. Warnings 🖄		6
1.4.2. Cautions 🛆		6
Prerequisites for Configuring the IEC	61850 Protocol	7
2.1. Configuring the project propert	ies	7
Configuring the IEC (1960 Server Dr		10
2.1. Adding the LEC 61850 Server pro	reteast	10
3.1. Adding the FEC 61850 Server p		. 10
3.3. Configuring the JEC 61850 Serv	ver protocol properties	12
3.4 Operating the equipment		14
3.4.1 Configuring the SBOns mod	del	15
3.4.2. Configuring the SBOes mod	Jel	18
3.4.3. Configuring the DOns mode	əl	. 21
3.4.4. Configuring the DOes mode	3]	23
3.4.5. Determining the circuit bread	aker position	26
3.4.7. Controlling an output throu	gh detection of rising edge	30
Configuring the IEC 61850 Client Pro	tocol	36
4.1 Adding the IEC 61850 Client pr	ratocol	36
4.2 Inserting a port		37
4.3. Adding the variables		. 38
4.3.1. Reading the variables from	the server	38
4.3.2. Reading the variables from	the SCL file configured on the server	. 39
4.4. Sending commands to the serv	er	39
4.4.1. Selecting a data attribute		39
4.4.2. Operating a data attribute .		42
4.4.5. Writing a value to a data at		. 44
Configuring the IEC 61850 GOOSE Pu	ublisher or Subscriber Protocol	46
5.1. Adding the IEC 61850 GOOSE p		46
5.2. Searching the MAC address of a	an Ethernet port	47
5.3. Inserting a communication port	Γ	48
5.4. Adding a GOUSE publisher		49
© 2013 Vizimax, Inc.	Vizimax	iv
All rights reserved.	www.vizimax.com	

5.5. Adding a GOOSE subscriber	51
5.6. Creating variables for unassigned objects	53
5.7. Description of data block parameters	54
5.8. Description of variable parameters	55
Appendix: Accessing the OEM Library	56

Revision History

Date	Comments	Author
(yy-mm-dd)		
2011-07-22	V1.0: Initial release.	C. Archambault
2011-11-11	V1.2: Update and addition of sections on IEC 61850	C. Archambault
	Client/Server configuration.	
2012-04-25	V1.3: Addition of program configuration using the SBOes,	M. Raymond
	DOns and DOes control models.	
2012-08-01	V1.4: Update of IEC 61850 protocol configuration.	C. Archambault
2013-06-11	V1.5: Update of DOns model.	C. Archambault

Document Applicability

This document applies to the following RightWON Configuration Suite software versions:

Document version	Product version	Comments
V1.0	1.6.x	
V1.2 to V1.3	1.7.x	
V1.4 and higher	1.8.0 and higher	 Supports Editions 1.0 and 2.0 of the IEC 61850 standard, but certified for Edition 1.0 only. Supports the IEC 61400-25 standard for monitoring and control of wind power plants.



1.1. About the IEC 61850 protocol

The IEC 61850 protocol is used to exchange data reliably between servers and clients over an Ethernet link. This protocol has been designed to meet the needs of distributed energy systems. The RightWON supports the IEC 61850 communication protocol in the following ways:

- 1. The IEC 61850 server allows the RightWON to make information available to multiple clients. A maximum of 16 clients can be simultaneously connected to a server.
- 2. The IEC 61850 client allows the RightWON to gather information from several servers. Typically, the server is a data generator whereas the client is a data consumer.
- 3. The GOOSE publisher/subscriber protocol allows the RightWON to exchange data rapidly with one or more Intelligent Electronic Devices (IEDs) during an event such as a change in a data value.

Each server or IEC 61850 GOOSE publisher has an SCL file that describes the specifications and capabilities of the Intelligent Electronic Devices used at the substations. To create a SCL file, refer to document *RWM000010-MA-en, RightWON Configuration Suite Manual.* Variables are created when the SCL file is imported into the IEC 61850 client or subscriber. Commands generated by the IEC 61850 client must be handled by an IEC 61131-3 PLC program using control models that are defined in the protocol. Data from these models must be handled using function blocks from IEC 61850 libraries. An IEC 61131-3 PLC program developed by the integrator typically reads the inputs/outputs on devices connected to the RightWON (for example an input/output system accessible via MODBUS or CANopen protocol) and feeds into the variables associated with the IEC 61850 protocol. The variables are grouped in a communication profile that permits timestamps and status/test bits, among others. Refer to the topic *Developing an IEC 61131-3 PLC automation program* in the document *RWM000010-MA-en, RightWON Configuration Suite Manual*.

1.1.1. SCL file description

Each server has an SCL (Substation Configuration Language) file that describes the specifications and capabilities of the Intelligent Electronic Devices (IEDs) used at the substations. This file is constructed using a specialized SCL editor. When imported by the client, the SCL file permits configuring the database without having to transcribe the information. All IEC 61850 applications are developed from the SCL file that describes the product functionalities (XCBR, GGIO, MMXU, etc.) and the data handled by the unit.

Property	Description
Header	The header identifies the SCL configuration file, its version and the name of the software used to create it. The header also specifies options for mapping names to signals.
Substation	Describes the substation entity or equipment to which the configuration applies. For example, this could be a power transformer or a circuit breaker.
Communications	Defines how the IEDs are connected to sub-networks, the communication access points, and describes the communication links between IEDs.
Services	Defines the services that are offered. Refer to the IEC 61850-6 standard for their descriptions.
Intelligent Electronic Devices, or IEDs	Includes the complete configuration of the Intelligent Electronic Devices (IEDs), including the various IED access points, LDevices and LNs (groups of functions). This section also contains IED data and reports, including the data retrieved or published by the GOOSE protocol.
Logical Device (LDevice)	Provides information (nameplate and service quality) about the physical peripheral devices used as hosts or the external devices they control.
Logical Nodes (LNs)	 The logical nodes of the logical device are combinations of predefined functions that are performed in the IED. The logical nodes that must be defined in every logical device are LLNO and LPHD: LLNO: Each logical device has only one logical node, LLNO, that represents the usual data of the logical device, for example SYNCHROTEQ. LPHD1: Each logical device has only one logical node for the physical device (LPHD). It represents the usual data of the physical device that hosts the logical device. There must also be at least one other logical node related to the application type. The IEC 61850-7-4 standard defines 91 logical nodes divided into 13 logical groups. The first letter of a node defines its group. The example uses the following logical nodes: GGIO is a logical node used to represent a primary or auxiliary generic device. It publishes analog and/or digital signals. MMXU is a logical node used to publish electrical measurements such as the RMS voltage, power or frequency. These values are normally used for operations such as supervision and management of power, screen display, status estimates, etc. The precision required for these functions must be specified.
Data Set	Each logical node includes datasets which permit grouping the data and data attributes.
Report Control Block	Describes the conditions for generating reports and logs based on parameters configured by the client. Reports can be sent immediately or delayed. Logs can be queried for later retrieval.
Data Object (DO)	A data object (DO) is contained in a logical node and describes the data attributes
and	(DAs). For a complete list of DAs refer to the IEC 61850-7-3 standard. For the DOs,
Data Attribute (DA)	refer to IEC 61850-7-4.
GOOSE type GSE	Logical nodes can support a fast and reliable distribution system for data input and
control block	output values in GOOSE format. GSE: Generic Substation Event.
Data Type	Permits specifying the Data Object (DO) and Data Attribute (DA) types that are in
Templates	an IED. The different values of these types can also be listed.
	A logical node as specified in the data type template is a model that can have
	ווועונוטופ וווזנמוונפז.

The IED description includes the following properties, as defined in the IEC 61850 standard:

1.1.2. Identification of data objects and data attributes

The variables are grouped into logical nodes and are composed of data objects and data attributes. The IEC 61850 protocol uses an XML data structure to describe them. The hierarchical structure used for naming and identifying the objects is the following:

Hierarchical structure

Example of an object ID Synchroteq/XCBR.Pos.stVal

Logical device Logical node Data object (DO) Data attribute (DA)

Note: For a complete list of DAs refer to the IEC 61850-7-3 standard. For DOs, refer to IEC 61850-7-4.

Abbreviation	Data object
AirFlwRte	Air flow rate
Beh	Behavior
Cancel	Cancel
EEName	External equipment name
Health	Health
Loc	Local mode
mag	Magnitude
mod	Operating mode
NamPlt	Nameplate
oper	Operation
origin	Origin
SBOw	Selection value

Table 1: Partial list of data object abbreviations

Table 2: Partial list of	f data	attribute abbreviations
--------------------------	--------	-------------------------

Abbreviation	Type(s)	Attribute
Check	UDINT	Check
configRev	STRING(255)	Configuration revision
ctIModel	SINT	Control model
ctINum	USINT	Control number
ctIVal	SINT, BOOL	Control value
d	STRING(255)	Device
dataNs	STRING(255)	Name space
db	UDINT	Deadband
f	REAL	Floating point
hwRev	STRING(255)	Hardware revision
Location	STRING(255)	City/region/country
model	STRING(255)	Model

multiplier	SINT	Multiplier
orCat	SINT	Origin category
orldent	STRING(255)	Origin identification
sboClass	SINT	SBO class
serNum	STRING(255)	Serial number
SIUnit	SINT	SI unit
stSeld	BOOL	Select
stVal	SINT, BOOL	Present status
swRev	STRING(255)	Software revision
Т	LREAL	Timestamp
Test	BOOL	Test
vendor	STRING(255)	Vendor

1.1.3. Description of control models for operating the equipment

The IEC 61850 protocol provides several control models for operating the equipment. The following models are supported by the RightWON:

- **Direct operation model with normal security (DOns):** This control model is the simplest. There is no need to select the object before executing an operation. There is no verification of the success or failure of the operation.
- **Direct operation model with execution status (DOes):** This control model permits executing an operation without prior selection of the object. In addition, it verifies the success of the operation. If the operation fails, an error message is sent.
- Select-before-operate model with normal security (SBOns): This control model requires that the client first select the object to be controlled before operating it within a specified time. If the time period elapses and the operation command has not been issued, the object is automatically deselected and cannot be operated unless the client selects it again and executes before the allotted time. Only one client at a time can select and operate an object. This model does not verify the success or failure of the operation.
- Select-before-operate model with execution status (SBOes): This model is identical to the SBOns model, but in addition verifies the success of the operation. If the operation fails, an error message is sent. The model supported by the RightWON is the dual point of control (DPC) type, which is used for implementing the XCBR (circuit breaker) type of logical node. DPC supports 2 outputs for controlling the circuit breaker (opening and closing) and two inputs for obtaining its position (open, closed, in transit, discordance).

1.1.4. Support of IEC 61850 features

The International Electrotechnical Commission (www.iec.ch) recognizes that it is not necessary to support all of the features offered by the IEC 61850 protocol. Only a certain number are required and all others are optional. The RightWON supports most of these features. Thus it is important to read the manufacturer's MICS, PICS, PIXIT and TICS. It is recommended to read the IEC 61850 standard for a better understanding of its integration.

1.1.5. Support of the IEC 61400-25 standard

The IEC 61400-25 standard is a communication standard for the monitoring and control of wind power plants. It is recommended to read the IEC 61400-25 standard for a better understanding of its integration.

© 2013 Vizimax, Inc.	Vizimax	4
All rights reserved.	www.vizimax.com	

1.2. Document scope

This document describes the integration of the IEC 61850 communication protocol in the RightWON system using the RightWON Configuration Suite software.

Note: You must register the license key on the platform before you can use it. You can obtain the license key from your sales representative.

1.2.1. Other documents

For further details on the information in this document, refer to the specific manuals below:

Reference No.	Document Name
RWM000010-MA	RightWON Configuration Suite Manual
RWM000050-MA	RightWON Satellite – User Guide
RWM000060-MA	RightWON Engine IEC61850-3 – User Guide
RWM000061-MA	RightWON Engine Rackmount – User Guide
RWM000062-MA	RightWON Engine Standalone – User Guide
RWM000080-MA	RightWON Configuration Suite – Application Guide

1.3. Document conventions

To facilitate the reading of this document the following conventions are used:

- Menu/dialog controls and items are in **bold**, e.g. **Options/Advanced settings...**, as are buttons, e.g. **OK**
- Names that are defined by the system integrators are in *italics*, e.g. *John Smith*, *Generator*
- Hyperlinks are in blue
- The \triangle symbol is used to raise the reader's attention.

1.4. Safety precautions

To ensure the safety of personnel and products, and to prevent the risk of accident, you must strictly follow the cautions and warnings written on product labels, in the manuals and on the RightWON product packaging.

To ensure proper operations of the RightWON product, read this manual in its entirety before proceeding to the other stages of learning, hardware installation, configuration or operation. Make sure that you fully understand the product and all information provided in this manual. For further information or if you require assistance, contact your sales representative (certain fees and conditions may apply, depending on the type of service requested).

1.4.1. Warnings 🛆

RightWON products are not designed for safety management applications or as security devices. Mishandling of this product could cause critical situations leading to personal, equipment or property damage, network failure, loss of data, electrical shock, serious injury or even death. To prevent such events from occurring:

- Take all possible measures to ensure the security of your systems through the use of appropriate equipment that meets the requirements of the application. This will help preserve the integrity of your systems in the event of product failure or other external factors.
- To prevent the risk of explosion, do not use RightWON products in areas where explosives are stored without taking appropriate measures as defined by the standards and regulations in effect, obtained from the proper local authorities.
- To prevent damage to electronic components, do not expose this product to open flame or submit it to environmental factors that exceed the recommended levels.
- Batteries may explode if they are not handled with care. Do not recharge, disassemble or dispose of in fire. We recommend that you recycle these items by taking them to the appropriate collection service.

1.4.2. Cautions 🛆

- Make sure that RightWON products are managed by qualified personnel who have been properly trained to install, configure and troubleshoot them.
- Always configure and operate this product within the technical specifications and operating criteria recommended by Vizimax, as cited in this manual and the other technical documents available.
- Use homologated external emergency devices, including but not limited to: emergency stop, emergency signaling, interlock and safety circuitry.
- Properly connect and secure removable cables and connectors. Loose connections could overheat and catch fire.
- Protect all power supplies and connect to ground on the equipment using an appropriate connection. Failure to protect and/or ground the equipment could lead to fatal electrical shock.
- Take all possible measures to prevent foreign materials from falling into the product interior (liquids, flammable materials, metal objects, etc.).
- Turn the equipment off and disconnect all sources of power before undertaking any procedure whatsoever on the equipment.



Prerequisites for Configuring the IEC 61850 Protocol

Before configuring the IEC 61850 protocol, make sure that the following steps have been carried out:

- To configure a port and an Ethernet link, refer to the topic *Configuring the unit* in the document *RWM0000010, RightWON Configuration Suite Manual.* The RightWON supports the IEC 61850 protocol on an Ethernet communication link using TCP/IP.
- Configure an SCL file using your SCL editor or the editor in the Configuration Suite. Refer to the document *RWM0000010, RightWON Configuration Suite Manual.* The editor must comply with the rules regarding data and SCL files defined in the IEC 61850-6 standard.
- 3. Configure the project properties to use status bits and user bits, and configure the compilation settings for IEC 61850.
- 4. Add the library of function blocks for the IEC 61850 server, referring to the document *RWM000010-MA-en*, *RightWON Configuration Suite Manual*. Contact your sales representative to obtain the library.

Note: A license is required to use the IEC 61850 protocol in the RightWON unit, but is not required to configure this protocol using the RightWON Configuration Suite. Refer to the topic *Activating your advanced feature license* in the document *RWM000010-MA-en, RightWON Configuration Suite Manual.*

2.1. Configuring the project properties

The IEC 61850 protocol supports timestamps and status bits associated with the data. By default, the project settings do not activate these functions.

To configure the status bits and user bits, and configure the compilation settings for IEC 61850, carry out the following steps:

1- If several projects are displayed in the Workspace, right-click the project and click **Set as Startup Project**.



2- Under the Project menu, click Settings...

🕌 RightWON Configurat	tion	5uite - Tutorial.w5l		
File Edit View Insert	Proj	ect Tools Window Help		
😂 🖬 🖻 🛃 🐰	₿	Build All Projects	F7	ur 🔍
Workspace		Clean All Projects		VCS Tute
🗄 🗐 GoosePublisher		Settings N		2
🗄 🧃 IEC61850Client				
in Tecci 850Serve	الكر	<u>O</u> n Line	Ctrl+F5	1
🗄 🚞 Exception pro	•~	Simulate	F5	1 1
🚊 🔤 Programs				
Main Main Main Main Main Main Main Main	هي ا	Stop/Restart Archinition	Ctrl+Shitt+F4	

The Project settings window appears.

3- Click on Advanced.

D:\Wor	kdir\testIEC61850
Target	
- 0	5 T5RTI: T5 Runtime for little endian processors
6	T5RTM: T5 Runtime for big endian processors
Code	eneration
0	Release Store complex variables in a
Ģ	Debug separate segment
Externa	al objects
U	se programs and UDFBs from other projects
Versior	1
۷	34 - built 2010/12/29 11:24:05
s	ee more options Advanced

- 4- Click the **Compiler** tab.
- 5- To use the VSI and user bits, click on the Allocate status flags for variables with embedded properties checkbox.

6- To configure the compilation settings for IEC 61850, enter **MAPUINT=ON** in the **Other options** box.

Project settings
Settings Runtime Compiler Memory Download Debug On Line Chan
Keep case of embedded symbols
Check safety of SPC charts
Remove code of unreferenced sub-programs
Check IEC conformity
Check multiple calls to FB instances
Allocate status flags for variables with embedded properties
Maximum number of error messages displayed: 128
- Runtime password
This password will be asked at any connection to the runtime
Password: 0 (number)
Other options
TRACETIME=OFF
MAPUINT=ON
Aways open this tab
OK Cancel Help

7- Click OK.



Configuring the IEC 61850 Server Protocol

Configuration of an IEC 61850 Server in the RightWON requires the following steps:

- 1- Review the prerequisites for configuring the IEC 61850 protocol
- 2- Add the IEC 61850 Server protocol to the RightWON configuration
- 3- Import the SCL file to create the variables
- 4- Configure the IEC 61850 Server protocol properties
- 5- Operate the equipment according to a control model

3.1. Adding the IEC 61850 Server protocol

If the IEC 61850 Server protocol was not added during creation of a new project, carry out the following steps to add it:

- 1- Double click on Fieldbus configurations 🚠.
- 2- Under the Insert menu, click Insert Configuration... 🖲.
- 3- Click on the IEC 61850 Server protocol.
- 4- Click **OK**.



3.2. Importing the SCL file

The variables are created when you import the SCL file. To do this, carry out the following steps:

- ▲ The latest file to be imported is the one that will be used. If variables from an old file are still present in the IEC 61850 profile when they are no longer used, the RightWON will issue errors and will not start the application. Thus you must delete the old variables first.
 - 1- Double-click on **Fieldbus configurations** $\frac{1}{4}$. The IO Drivers window opens.
 - 2- Right-click on IEC 61850 Server.
 - 3- Click Read variables from SCL file.

IO Drivers *	
CAN Open bus	Name
IEC 61850 Server	May number of saver
Mobbus Mester protoco	Properties
📕 🗄 Modbus Slave protocol 🔪	Chara -
🗢 🗄 🌠 RightWON 📃 🔨	Gear
📊 🗄 🗊 Hardware 🛛 👗	Cut
💾 🗄 🖅 Network	Сору
💾 🗄 🦠 Remote Management 🛒	Paste
č)	
	Eind
	Find Next
	·
	Insert Configuration
	Insert Master/Port
48	Insert Slave /Data Block
0	Inse <u>r</u> t Variable
B1	Sort symbols
8*	
	<u>G</u> rid Ctrl+G
	Read variables from SCL file
	h

4- Click Insert.

Selec	variables	×
) Server	
Mo	I Insert Cancel	

- 5- Select your SCL file.
- 6- Click Open.



- 7- To insert all of the variables, check the Server checkbox. If you are loading a new version of the file, the items that are already present are checked and in bold.
- 8- Click **OK**.



3.3. Configuring the IEC 61850 Server protocol properties

After adding the IEC 61850 Server protocol, configure its properties by carrying out the following steps:

- 1- Click on the IEC 61850 Server.
- 2- To configure the parameters that follow:
 - a. Double-click on the parameter field.
 - b. Enter the value according to the requirements of the application. Refer to the following table for parameter descriptions.
 - c. Press the Enter key.

_							
101	IO Drivers *						
E	IEC 61850 Server	Name	Value				
무	🗄 🕎 RightWON	Max. number of saved BRCBs	1000				
**日		Max. number of incoming connections	16				
E		Max. number of dynamic datasets	20				
0		Max. number of dynamic dataset members	50				
		Override IED name (active if not empty)					
		Use VSI for flags and TimeStamp	Use Std VSI and User bits (1-8)				
		Keep alive delay	2				
ġ,s		Keep alive max retry	8				
205							

Parameter	Description
Max. number of saved BRCBs (Buffered Report Control Blocks)	Maximum number of control blocks for buffered reports (from 1 to 1000).
Max. number of incoming connections	Maximum number of simultaneous incoming connections (from 1 to 16). This defines the maximum number of clients.
Max. number of dynamic datasets	Maximum number of dynamic datasets (from 1 to 16).
Max. number of dynamic dataset members	Maximum number of members in a dynamic dataset (from 1 to 50)
Override IED name	Permits replacing the IED name defined in the SCL file with the name specified in this field. This parameter is inactive when the field is empty.
Use VSI for flags and TimeStamp	Permits the use of quality/test bits and timestamps according to the following options:
	 If you do not wish to use the status bits associated with the variables (VSI), click Don't use VSI.
	 To use the status bits associated with the variables (VSI), click Use Std VSI.
	• To use the status bits associated with the variables (VSI) and the user bits (1-8), click Use Std VSI and User bits (1-8) .
Keep alive delay	Delay between keep alive signals for keeping the communication link up.
Keep alive max retry	Maximum number of retries after the failure of a keep alive signal.

3.4. Operating the equipment

To be able to operate the equipment, you must use the model that was defined in the SCL file configuration:

- 1. Add a new program in the **FBD-Function block diagram** language. Refer to the topic *Developing IEC 61131-3 PLC automation applications* in the document *RWM000010-MA-en, RightWON Configuration Suite Manual.*
- 2. In the Workspace, double-click on the FBD program in the **Programs** folder.

3. Select the control model to be used:

NOTE: For further information on the types of nodes, DOs and DAs, refer to the IEC 61850-7-3 and IEC 61850-7-4 standards.

- Configuring the SBOns model.
- Configuring the SBOes model.
- Configuring the DOns model.
- Configuring the DOes model.
- 4. Control the output in order to operate the equipment.

3.4.1. Configuring the SBOns model

To configure the SBOns model, carry out the following steps:

1- Select and drag the **SBOns** function in the IEC61850 folder from the list of functions to the editing area of the program.



- 2- Double-click on the ??? box at the top of the block.
- 3- Enter a variable name in the block, for example *inst_Fan1*.
- 4- Click on the green checkmark.

GGIO *		
	,	_
Ð	linst Fan1	
	???\$	
	??? 🚽 👘 🗛 (AUX/GGIO1.Fan1.Č 🔺	
	??? 🚽 👘 🗛 🖓 🖓 🖓 🖓 🖓 🕹	
1	??? ——————————————————————————————————	4
)(??? 🚽 🖉 🖓 🖓 🖓 🖓 🖓 🖓 🖓	
- e -	??? 🚽 🖉 🚽 🖓 🖓 🖓	
	??? ——————————————————————————————————	
	??? 🚽 🖉 🚽 🖓 🖓 🖓 🖓	
lake.	??? 🚽 👘 🖓 🖓 🖓 🖓 🖓 🖓 👘	1
100.	??? —ÉLI 🖌 🕨	
→>	??? \$	1
	??? Variables: (all)	1
F	📶 🗖 Local variables only	
-IF	Hide FB instances	

If the variable does not exist, a window appears for declaring a new variable.

5- Click **Yes** to declare the new variable.

inst_Fan1		×
This symbol	does not exist. Do you want to:	
 C Rename O Declare 	: the variable a new variable	
Type:	SBOns	
Where:	GGIO	▼
Ye	No No	Cancel

- 6- To configure the inputs and outputs of the block:
 - a. Double-click the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file
SBO_timeout	Input	LDevice_XCBR1_Pos_sbo_Timeout
Operate_originator	Input	LDevice_XCBR1_Pos_Oper_origin_orIdent
CTRL_int	Input / Output	LDevice_XCBR1_Pos
Blocked_close	Input	LDevice_XCBR1_BlkCls.stVal or enter 0 to not use.
Blocked_open	Input	LDevice_XCBR1_BlkOpn.stVal or enter 0 to not use.
Operate_ctIVal	Input	LDevice_XCBR1_Pos_Oper_ctlVal
Beh	Input	LDevice_XCBR1_Beh_stVal
Cancel_Originator	Input	LDevice_XCBR1_Pos_Cancel_origin_orIdent
Oper_Cat	Input	LDevice_XCBR1_Pos_Oper_origin_orCat
Local_in	Input	To determine whether the unit is in local or remote mode, enter the name of a new Boolean variable, for example <i>bLocal</i> .
Status_In	Input	LDevice_XCBR1_Pos_stVal
Test_oper	Input	LDevice_XCBR1_Pos_Oper_Test
Value_Out	Output	Enter the name of a new Boolean variable, for example <i>bValueOut</i> . This output is the value that you wish to control.
Q_action	Output	Enter the name of a new Boolean variable, for example <i>bQAction</i> . This output sends a one-second pulse in high state when a valid command goes through. Thus it must be associated with a new variable that will be used to trigger a change in value on output.

7- The SBOns block is now configured; see the example in the figure below.

GGI	0 *				
11					
		SBOns			
Ð	{AUX/GGIO1.Fan2.sboTimeout}		Value_out	bValueOut	
-	{AUX/GGIO1.Fan2.Oper.origin.orldent}	Operate_originator	Q_action	bQAction	
0	{AUX/GGIO1.Fan2}	CTRL_int			
•••	0				
	0	-Blocked_open			
7-1	{AUX/GGIO1.Fan2.Oper.ctlVal}				
-9-	{AUX/GGIO1.Beh.stVal}	— Beh			
	{AUX/GGIO1.Fan2.Cancel.origin.orldent}				
	{AUX/GGIO1.Fan2.Oper.origin.orCat}	Oper_Cat			
	bLocal	Local_in			
lab:	{AUX/GGIO1.Fan2.stVal}	Status_in			
≫	{AUX/GGIO1.Fan2.Oper.Test}				

3.4.2. Configuring the SBOes model

To configure the SBOes model, carry out the following steps:

1- Select and drag the **SBOCtIBin** function in the IEC61850 folder from the list of functions to the editing area of the *XCBR* program.



- 2- Double-click on the ??? box at the top of the block.
- 3- Enter a variable name in the block, for example inst_XCBR1.
- 4- Click on the green checkmark.

XCBR *		· · · · · · · · · · · · · · · · · · ·
		2777 2
-	222	🔄 🔬 inst_XCBR1 🛛 💉 🗙
ъ <u> </u>	222	
	777	
	???	→ 🖓 🗠 🛄 bLocal
L.	???	——Ķ₿
	???	📕 🚽 📴 bQAction
•	???	🔰 🚽 🎼 🗋 bValueOut
	???	🗾 — 🤄 LDevice_LLN0_Beh_stVal
	???	🗾 🚽 🍎 🔄 🚽 LDevice_LLN0_GCB1_GoEna 🛛 🚽
L.L.	???	
100.	???	
→ >	???	Variables: (all)
	???	🗾 🚽 🖉 Local variables only
F	???	🗾 🚽 🖾 Hide FB instances
#	???	ČOpe 3
+	???	test
-	???	che
0 -	???	Heal
-	???	Ope

5- Click **Yes** to accept creation of the variable.

inst_XCBR1		×
This symbol	I does not exist. Do you want to:	
C Rename	e the variable	
O Declare	a new variable	
Туре:	SBOCtlBin	
Where:	XCBR	
Y	es No Cancel	

- 6- To configure the inputs and outputs of the block:
 - a. Double-click the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

XCB	R *			
		inst	XCBR1	
Ð	TV////////////////////////////////////	SBO	DCtlBin	
\odot	Z ??? K—∎SBO time	out	BRK_open	???
	LDevice XCBR1 Pos sboTimeout	iginator	BRK_close	???
		inator	Pos_origin	???
1	💿 🔤 LDevice_XCBR1_Pos_pulseConfig_nu 🔺		Pos_ctlNum	???
-	LDevice_XCBR1_Pos_pulseConfig_off	pse	Latest_oper_OrCat	???
-9-	LDevice_XCBR1_Pos_pulseConfig_or	en		
	LDevice_XCBR1_Pos_sboClass			
Ħ	LDevice_XCBR1_Pos_sboTimeout			
lake	LDevice_XCBR1_Pos_SBOw_Check	a l		
inter.	LDevice_XCBR1_Pos_SBOw_ctlNum 💷 🛛			
≫	🖉 🖳 🖕 LDevice_XCBR1_Pos_SBOw_ctIVal 🔎	ginator		
F				
Ŧ	Variables: (all)			
#	Local variables only	m		
-1	📃 🔚 Hide FB instances			
0 ⁱ	???? check_op	er		
H.	??? —I Health_st	Val		
-	??? Operate_ti	imeout		

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file
SBO_timeout	Input	LDevice_XCBR1_Pos_sbo_Timeout
Operate_originator	Input	LDevice_XCBR1_Pos_Oper_origin_orIdent
Select_originator	Input	LDevice_XCBR1_Pos_SBOw_origin_orIdent
CTRL_int	Input / Output	LDevice_XCBR1_Pos
Blocked_close	Input	LDevice_XCBR1_BlkCls.stVal
Blocked_open	Input	LDevice_XCBR1_BlkOpn.stVal
Select_req	Input	LDevice_XCBR1_Pos_SBOw_ctlVal
Pos_stVal	Input	LDevice_XCBR1_Pos_stVal
Operate_req	Input	LDevice_XCBR1_Pos_Oper_ctlVal
Beh	Input	LDevice_XCBR1_Beh_stVal
Cancel_Originator	Input	LDevice_XCBR1_Pos_Cancel_origin_orIdent
Select_Cat	Input	LDevice_XCBR1_Pos_SBOw_origin_orCat
Oper_Cat	Input	LDevice_XCBR1_Pos_Oper_origin_orCat
Local_in	Input	To determine whether the unit is in local or remote mode, enter the name of a new Boolean variable, for example <i>bLocal</i> .
Oper_ctINum	Input	LDevice_XCBR1_Pos_ctINum
Test_oper	Input	LDevice_XCBR1_Pos_Oper_Test
Check_oper	Input	LDevice_XCBR1_Pos_Oper_Check
Health_stVal	Input	LDevice_XCBR1_Health_stVal
Operate_timeout	Input	Enter a number in milliseconds, for example 3000.
BRK_open	Output	Enter the name of a new Boolean variable, for example <i>bBRK_Open</i> . This output goes to high state during a circuit breaker opening command.
BRK_close	Output	Enter the name of a new Boolean variable, for example <i>bBRK_Close</i> . This output goes to high state during a circuit breaker closing command.
Pos_origin	Output	LDevice_XCBR1_Pos_origin_orIdent
Pos_ctINum	Output	LDevice_XCBR1_Pos_ctINum
Latest_oper_OrCat	Output	LDevice_XCBR1_Pos_origin.orCat

7- The SBOes block is now configured; see the example in the figure below.

XCB	R*			
_		inst_)	(CBR1	
Ð		SBO	CtlBin	
\square	LDevice_XCBR1_Pos_sboTimeout		BRK_open	bBRK_Open
_	LDevice_XCBR1_Pos_Oper_origin_orldent	Operate_originator	BRK_close	bBRK_Close
	LDevice_XCBR1_Pos_SBOw_origin_orldent		Pos_origin	LDevice_XCBR1_Pos_origin_orldent
1	LDevice_XCBR1_Pos	CTRL_int	Pos_ctlNum	LDevice_XCBR1_Pos_ctlNum
5	LDevice_XCBR1_BlkOpn_stVal	-Blocked_close	Latest_oper_OrCat	LDevice_XCBR1_Pos_origin_orCat
-9-	LDevice_XCBR1_BlkOpn_stVal	-Blocked_open		
	LDevice_XCBR1_Pos_SBOw_ctlVal			
H	LDevice_XCBR1_Pos_stVal			
Lake	LDevice_XCBR1_Pos_Oper_ctlVal	Operate_req		
100.	LDevice_XCBR1_Beh_stVal	Beh		
≫	LDevice_XCBR1_Pos_Cancel_origin_orldent			
	LDevice_XCBR1_Pos_SBOw_origin_orCat	-Select_Cat		
F	LDevice_XCBR1_Pos_Oper_origin_orCat	Oper_Cat		
Ŧ	bLocal			
+	LDevice_XCBR1_Pos_ctlNum	Oper_ctlNum		
- A.	LDevice_XCBR1_Pos_Oper_Test			
OF	LDevice_XCBR1_Pos_Oper_Check			
-	siHealthXCBR1			
_	3000			

3.4.3. Configuring the DOns model

To configure the DOns model, carry out the following steps:

1- Select and drag the **DOns** function in the IEC61850 folder from the list of functions to the editing area of the *XCBR* program.



- 2- Double-click on the ??? box at the top of the block.
- 3- Enter a variable name in the block, for example instXCBR1BlkCls.
- 4- Click on the green checkmark.

XCE	R *
	in the second
₽	222 instXCBR1BlkCls
	??? —ģ8b52a
_	??? —ÉL — 🔂 b52b
Ч	??? — 🗘 bBRK_Close
-9-	??? — 🖉 H 🔤 🖓 bBRK_Open
_	??? — 🥵 🔤 bLocal
H	📶 🔤 🔂 🖉
1.1.	📃 🔤 bValueOut 📃
IQD:	
≫	Variables: (all)
L	
	Local variables only
₽	I Hide FB instances

5- Click **Yes** to accept creation of the variable.

instXCBR18	BlkCls	×			
This symbol does not exist. Do you want to:					
C Renam	e the variable				
O Declare	O Declare a new variable				
Type:	Type: DOns				
Where: XCBR					
		_			
Y	es No Cancel				

- 6- To configure the inputs and outputs of the block:
 - a. Double-click the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file		
CTRL_int	Input / Output	LDevice_XCBR1_BlkCls		
Operate_ctIVal	Input	LDevice_XCBR1_BlkCls_Oper_ctlVal		
Beh	Input	LDevice_XCBR1_Beh_stVal		
Local_in	Input	To determine whether the unit is in local or remote mode, enter the name of a new Boolean variable, for example <i>bLocal</i> .		
OrCat	Input	LDevice_XCBR1_BlkCls_Oper_origin_orCat		
Health_stVal	Input	LDevice_XCBR1_Health_stVal		
Test_oper	Input	LDevice_XCBR1_BlkCls_Oper_Test		
Out_cmd	Input / Output	LDevice_XCBR1_BlkCls_stVal		
Last_oper_OrCat	Output	LDevice_XCBR1_BlkCls_origin_orCat		
Last_oper_origin	Output	Select the variable and delete it.		

7- The DOns block is now configured; see the example in the figure below.

XC	3R *			
			W000401 01	
_		Ins	SIXUBRIBIKUIS	
관			DOns	
	LDevice_XCBR1_BlkCls	CTRL_int	Last_oper_OrCat	LDevice_XCBR1_BlkCls_stVal
	LDevice_XCBR1_BlkCls_Oper_ctlVal		Last_oper_origin_ident	
	LDevice_XCBR1_Beh_stVal	— Beh		
	bLocal	Local_In		
1.54	LDevice_XCBR1_BlkCls_Oper_origin_orCat	- OrCat		
-9-	LDevice_XCBR1_Health_stVal			
	LDevice_XCBR1_BlkCls_Oper_Test	Test		
	LDevice_XCBR1_BlkCls_stVal	Out_Cmd		

3.4.4. Configuring the DOes model

To configure the DOes model to control the equipment, carry out the following steps:

1- Select and drag the **DOes** function in the IEC61850 folder from the list of functions to the editing area of the *XCBR* program.



- 2- Double-click on the ??? box at the top of the block.
- 3- Enter a variable name in the block, for example *inst_XCBR2*.
- 4- Click on the green checkmark.



5- Click **Yes** to accept creation of the variable.

inst_XCBR2		×
This symbol does not exist. Do yo	iu want to:	
C Rename the variable		
Declare a new variable		
Type: DOes		
Where: XCBR		•
Yes	No	Cancel

- 6- To configure the inputs and outputs of the block:
 - a. Double-click the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file
Operate_originator	Input	LDevice_XCBR1_Pos_Oper_origin_orIdent
CTRL_int	Input / Output	LDevice_XCBR1_Pos
Blocked_close	Input	LDevice_XCBR1_BlkCls.stVal or enter 0 to not use.
Blocked_open	Input	LDevice_XCBR1_BlkOpn.stVal or enter 0 to not use.
Feedback	Input	Enter a variable name, for example <i>bD01</i> .
Operate_ctlVal	Input	LDevice_XCBR1_Pos_Oper_ctlVal
Beh	Input	LDevice_XCBR1_Beh_stVal
Cancel_Originator	Input	LDevice_XCBR1_Pos_Cancel_origin_orIdent
Oper_Cat	Input	LDevice_XCBR1_Pos_Oper_origin_orCat
Local_in	n Input To determine whether the unit is in local or remote moname of a new Boolean variable, for example <i>bLocal</i> .	
Test	Input	LDevice_XCBR1_Pos_Oper_Test
Health_stVal	Input	LDevice_XCBR1_Health_stVal
BRK_open	Output	Enter the name of a new Boolean variable, for example <i>bBRK_Open</i> . This output goes to high state during a circuit breaker opening command.
Value_Out	Output	Enter the name of a new Boolean variable, for example <i>bValueOut</i> .
	_	This output is the value that you wish to control.
Q_action	Output	Enter the name of a new Boolean variable, for example <i>bQAction</i> . This output sends a one-second pulse in high state when a valid command goes through. Thus it must be associated with a new variable that will be used to trigger a change in value on output.

7- The DOes block is now configured; see the example in the figure below.



3.4.5. Determining the circuit breaker position

To determine the circuit breaker position from an input/output or via remote inputs, carry out the following steps:

1- Select and drag the **BRK_position** function in the IEC61850 folder from the list of functions to the top of the *XCBR* program editing area.

You must put this function above the other blocks that use the **Pos_stVal** variable, so that it will be executed first.

- 2- To configure the inputs and outputs of this function:
 - a. Double-click the **???** of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file
BRK_52a	Input	Choose the input variable that corresponds to contact 52a on the circuit breaker, for example <i>b52a</i> .
BRK_52b	Input	Choose the input variable that corresponds to contact 52b on the circuit breaker, for example <i>b52b</i> .
Pos_stVal	Output	LDevice_XCBR1_Pos_stVal

3- The block is now configured; see the example in the figure below.

XCE	R*			
	BRK_position			
Ð	b52aBRK_52a Pos_s	stVal LDevice_XCBR1_	Pos_stVal	
\Box	b52b BRK_52b			
E.				
_		inst 1	(0001	
Ъщ		inst_/	CtIPin	
- o -	Device YCBR1 Pos shoTimeout	SBO timeout	BRK open	hBRK Open
	L Device XCBR1 Pos Oper origin orident	Operate originator	BRK close	bBRK_Close
H	Device XCBR1 Pos SBOw origin orident	Select originator	Pos origin	Device XCBR1 Pos origin orldent
	L Device_XCBR1_Pros	CTRL int	Pos. ctlNum	L Device XCBR1 Pos ctINum
lab:	Device XCBR1 BlkOnn stVal	Blocked close	Latest oper OrCat	Device XCBR1 Pos origin orCat
→ >	LDevice XCBR1 BlkOon stVal	Blocked open	concordependiente	
	LDevice XCBR1 Pos SBOw ct/Val	Select_reg		
H	LDevice XCBR1 Pos stVal	- Pos stVal		
-IF-	LDevice XCBR1 Pos Oper ctlVal	Operate reg		
<u> </u>	LDevice XCBR1 Beh stVal	-Beh		
=	LDevice XCBR1 Pos Cancel origin orlden	t - Cancel Originator		
()+	LDevice XCBR1 Pos SBOw origin orCat	- Select Cat		
-	LDevice_XCBR1_Pos_Oper_origin_orCat	Oper_Cat		
	bLocal	Local_in		
Q	LDevice_XCBR1_Pos_ctlNum			
-	LDevice_XCBR1_Pos_Oper_Test	test_oper		
800	LDevice_XCBR1_Pos_Oper_Check	check_oper		
8	siHealthXCBR1			
Jer	3000			

3.4.6. Controlling pulse outputs

To control pulse outputs, carry out the following steps:

1- Select and drag the **Pulse_cmd** function in the IEC61850 folder from the list of functions to the editing area of the program.



- 2- Double-click on the ??? box at the top of the block.
- 3- Enter a variable name in the block, for example Pulse_XCBR1.
- 4- Click on the green checkmark.



If the variable does not exist, a window appears for declaring a new variable.

5- Click **Yes** to declare the new variable.

Pulse_XCBR1		×			
This symbol does not e	This symbol does not exist. Do you want to:				
C Rename the variab	le				
💿 Declare a new vari	able				
Type: Pulse_cmd					
Where: XCBR		_			
Yes	No	Cancel			

- 6- To configure the inputs and outputs of the block:
 - a. Double-click the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Global variable to insert , varies depending on the data object (for example <i>Pos</i>) to be controlled and the configuration of the <i>LDevice</i> and <i>XCBR1</i> names in the SLC file		
BRK_open	Input	Click Add arc and connect the <i>BRK_open</i> output on a control model block to the <i>BRK_open</i> input on the <i>Pulse_cmd</i> block.		
BRK_close	Input	Click Add arc and connect the <i>BRK_close</i> output on a control model block to the <i>BRK_close</i> input on the <i>Pulse_cmd</i> block.		
Pulse_onDur	Input	LDevice_XCBR1_Pos_pulseConfig_onDur		
Pulse_offDur	Input	LDevice_XCBR1_Pos_pulseConfig_offDur		
Pulse_cmdQual	Input	LDevice_XCBR1_Pos_pulseConfig_cmdQual		
Pulse_numPls	Input	LDevice_XCBR1_BlkOpn_pulseConfig_numPls		
Open_Out	Output	Enter the name of a new Boolean variable, for example <i>DO02</i> . This output sends a pulse according to the ON duration (Pulse_onDur) and OFF duration (Pulse_offDur).		
Close_Out	Output	Enter the name of a new Boolean variable, for example <i>DO03</i> . This output sends a pulse according to the ON duration (Pulse_onDur) and OFF duration (Pulse_offDur).		

7- The block is now configured; see the example in the figure below.



3.4.7. Controlling an output through detection of rising edge

When a rising edge is detected on the *Q_Action* output of a control model, set an output variable, for example *bQ01*, to the value of the *Value* output of the model.

To do this, carry out the following steps:

- 1- Click the Add left power rail icon.
- 2- Click and drag the power rail <u>below the control model block</u> in the editing window of the program.



- 3- Click the Add direct contact icon.
- 4- Click and drag the contact to the desired location in the editing window of the program. It will attach itself to the power rail. Otherwise, click the **Add arc** icon and connect the power rail to the contact.



- 5- To configure this contact:
 - a. Double-click on the contact.
 - b. Assign the name of the variable that is associated with the *Q_action* output of the SBOns or DOes model function block.
 - c. Click on the green checkmark.



d. While the contact is selected, press the **Space** key repeatedly until the letter **P** appears in the middle of the contact.





- 7- Configure the function:
 - a. Delete the variables for the first input and the output of the function.



b. Click the Add arc icon and connect the contact to the first input of the function.



c. Double-click the second input of the function and assign the name of the variable that is associated with the *Value_Out* output of the SBOns or DOes model function block. Click on the green checkmark.



- 8- Click the Add direct coil icon.
- 9- Click and drag the coil to the desired location in the editing window of the program.



10-Configure the coil:

- a. Click the Add arc icon and connect the output of the function to the coil.
- b. Double-click the coil and enter the name of the output variable, for example *bQ01*. Click on the green checkmark.
- c. While the coil is selected, press the **Space** key repeatedly until the letter **S** appears in the middle of the coil.



11-Right-click on the contact and click Copy.



12-Right-click in the editing window and click **Paste**. Click in the window and move the contact to the desired location in the editing window of the program.It will attach itself to the power rail. Otherwise, click the **Add arc** icon and connect the

power rail to the contact.



13-Add an & (*Boolean AND*) function.



14-Configure the function:

- a. Delete all the input and output variables of the function.
- b. Click the **Add arc** icon and connect the first input of the function to the second contact.
- c. Add a **NOT (*Boolean inversion*)** function and delete the output variable.
- d. Click the **Add arc** icon and connect the output of the NOT function to the second input of the & function.
- e. In the input of the NOT function, assign the name of the variable that is associated with the *Value_Out* output of the SBOns or DOes model function block.



15-Click the Add direct coil icon.

16-Click and drag the coil to the desired location in the editing window of the program.



17-Configure the coil:

- a. Click the Add arc icon and connect the output of the function to the coil.
- b. Double-click the coil and assign the same output variable name as for the other coil. Click on the green checkmark.
- c. While the coil is selected, press the **Space** key repeatedly until the letter **R** appears in the middle of the coil.





Configuring the IEC 61850 Client Protocol

Configuration of an IEC 61850 Client in the RightWON requires the following steps:

- 1- Review the prerequisites for configuring the IEC 61850 protocol
- 2- Add the IEC 61850 Client protocol
- 3- Insert an IEC 61850 Server
- 4- Add the variables
- 5- Configure the program

For further information, refer to the IEC 61850-7 standard.

4.1. Adding the IEC 61850 Client protocol

If the IEC 61850 Client protocol was not added during creation of a new project, carry out the following steps to add it:

- 1- Double click on Fieldbus configurations 🏭
- 2- Under the Insert menu, click Insert Configuration... 🗏
- 3- Click on the IEC 61850 Client protocol.
- 4- Click OK.



- 5- To configure the parameters that follow:
 - a. Double-click on the parameter.
 - b. Enter the value in accordance with the requirements of the application. Refer to the following table for parameter descriptions.
 - c. Press the Enter key.

Parameter	Description		
Queue all value changes	Check the box to use queuing of state changes.		
Client IED Name	Enter the name of the client IED.		
VSI Mode	Permits the use of quality/test bits and timestamps according to the following options:		
	 If you do not wish to use the status bits associated with the variables (VSI), click No VSI. 		
	• To use the status bits associated with the variables (VSI), click VSI.		
	 To use the status bits associated with the variables (VSI) and the user bits (1-8), click VSI + User bits. 		

C:\U	C:\Users\IT\Desktop\test_engine - IO Drivers							
E	IEC 61850 Client	Name	Value					
문		Queue all value changes	 Image: A set of the set of the					
***		Client IED Name	client					
E		VSI mode	VSI + User bits					
÷								

4.2. Inserting a port

The port permits establishing a connection to the IEC 61850 Server. To add and configure it, carry out the following steps:

1- In the IO Drivers window, right-click on IEC 61850 Client and click Insert Master/Port...



- 2- Double-click on the **Server ID** property.
- 3- Enter the server ID.
- 4- Press the Enter key.
- 5- Double-click on the IP Address property.
- 6- Enter the IP address of the server.
- 7- Then press the Enter key.
- **Note:** For information on parameter descriptions refer to the **IEC61850 Client** topic in the RightWON Configuration Suite Help, accessed by pressing the **F1** key.

Server 0: TEST		×
Properties	Value	ОК
Server ID	0	
IP Address	216.208.233.181	Lancel
Port	102	Help
[Advanced parameters]		
Keepalive delay	2	
Keepalive retry	8	
Calling AP Title	1.1.1.999	
Calling AE Qualifier	12	
Called AP Title	1.1.999.1.1	
Called AE Qualifier	12	
Use preconfigured TrgOpts		
Enable tissue #453 BRCB		
Purge BRCB on cold start	▼	

4.3. Adding the variables

Variables can be added by either reading them directly from the server or from a copy of the server's SCL file.

4.3.1. Reading the variables from the server

To have the variables read from the server, carry out the following steps:

- 1. Make sure that the server is up and running, and that it is on the same network. Contact your network administrator, if required.
- 2. Right-click on the Server and click Read variables from server.



4.3.2. Reading the variables from the SCL file configured on the server

To use a copy of the SCL file configured on the server, carry out the following steps:

- 1. Right-click on the **Server**.
- 2. Click Read variables from SCL file.



4.4. Sending commands to the server

To send commands to the server, the control model defined by the server must be used. To do this, carry out the following steps:

- 1- Add a new program in the **FBD-Function block diagram** language. Give it a name, for example *Select_Oper*. Refer to the topic *Developing an IEC 61131-3 PLC automation program* in the document *RWM000010-MA-en*, *RightWON Configuration Suite Manual*.
- 2- Send a command by configuring the program in accordance with the control model of the data object (DO):
 - When the data attribute's DO follows the SBOns or SBOes control model: Select the data attribute of the DO before operating it.
 - When the data attribute's DO follows the DOns or DOes control model: Operate the data attribute of the DO directly.
 - When the data attribute's DO follows no control model, write the value to a DA.

4.4.1. Selecting a data attribute

In order to select an object, carry out the following steps to configure the IEC61850_SELECT function block.

Note: Depending on your application, it may be possible to select the object directly with the IEC61850_OPER operating function without having to use the IEC61850_SELECT function. Consult the section Operating a data attribute.

© 2013 Vizimax, Inc.	Vizimax	39
All rights reserved.	www.vizimax.com	

 Select and drag the IEC61850_SELECT function block from the list of blocks to the editing window of the program.



This function block permits selecting an operation on the data point.

- 2- Double-click on the **???** box at the top of the IEC61850_SELECT block. Enter the name of the block, for example *Select_pos*. Then click on $\sqrt{}$.
- 3- Click Yes to declare the new variable.
- 4- Configure the inputs and outputs of the function block:
 - a. Double-click on the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Data type	Parameter configuratio	n				
ENABLE	Input	BOOL	Enter <i>true</i> to enable the function, otherwise enter <i>false</i> to disable it.					
SERVERID	Input	UDINT	Enter the Server ID number.					
			IO Drivers					
			😑 🖃 🛄 IEC 61850 Client	Name	Value			
			🖳 📄 🚠 Server 0: STEQ1	Name	STEQ1			
			👘 🗄 👘 🗄 (RP) RWONCPUSY	Server ID	0			
			📕 🗄 📲 (RP) RWONCPUSY!	IP Address	172.16.30.236			
			💬 🗄 🚾 RightWON	Port	102			
РАТН	Input	STRING	Enter the path for the <i>Oper.ct/Val</i> variable of the data object (DO) to be selected. To do this: a In the IO Drivers window click on a variable					
			h Take note of the Dath field					
			D. Take note of the Patr	n Heid.				

Document No. RWM002030-MA-en

D:\Workdir\!RightW0	ON document	s\!RWCS Tutoriel\I	EC61850\IEC61850C	lient - 10 Drivers	*
📙 🖃 🛄 IEC 61850	0 Client			Name	Value
🔒 📄 🚠 Server	0: Server			Name	Server_CB1LDevice_XCBR1_Pos_Oper_ctWal_CO
📲 🗄 🗄 👘	ata of (CB1LDev	vice/LLN0)]		Variable Type	Data Attribute
📕 🕀 🖽 [Da	ata of (CB1LDev	vice/LPHD1)]		Path	CB1LDevice/XCBR1/Pos/Oper.ct/Val[CO]
🗢 😑 🔁 (Da	ata of (CB1LDev	vice/XCBR1)]		IEC Type	BOOL
	CB1LDevice/X	CBR1/Pos/Oper.ctN	Val(CO)		
	CB1LDevice/X	CBR1/Pos/Oper.ori	gin.orCat[CO]		
	CB1LDevice/X	CBR1/Pos/Oper.orig	gin.orldent[CO]		
			 c. In the prifield. d. Enter the name, for characteristic characteristic e. Then clicit 	rogram, dou e path betw or example er string. ck on √. bTrigSel1 bTrigSel2 bTrigSel1 bTrigSel2	uble-click on the ??? box next to the PATH veen single quotes (') and without the server ' <i>PATH</i> ', so that it will be recognized as a
СНЕСК	Input	USINT	Enter the type executing a <i>definitions</i> in (For further	pe of verific control ope n the OEM L informatior	ation that an object must carry out before ration. See the topic <i>IEC 61850 Check value</i> .ibrary. n, refer to the IEC 61850-7-2 standard.)
VALUE	Input	All types	Enter the na the data poi is to be cont	ame of a glo nt (DO) in o trolled and i	bal variable whose value must be written to order to operate. In the example, the <i>Pos</i> DO s a Boolean data type.
STATUS	Output	UDINT	Enter the na the comman for the statu Library.	ame of the v nd. For a list us output of	variable that indicates the present status of t of status indications, see the topic <i>Result</i> 61850 master command blocks in the OEM
RESULT	Output	DINT	Enter the na to be execut For a list of 61850 mast	ame of the o ted, in acco results, see fer comman	butput variable for the result of the command rdance with the IEC 61850 control model. the topic <i>Result for the result output of</i> <i>d blocks</i> in the OEM Library.



5- Operate the data attribute.

4.4.2. Operating a data attribute

To operate the object, carry out the following steps:

1- Select and drag the **IEC61850_OPER** function block from the list of blocks to the editing window of the program.



This function block permits executing an operation on the data point.

- 2- Double-click the **???** box at the top of the IEC61850_OPER function block. Enter the name of the block, for example *Oper_pos*. Then click on $\sqrt{}$.
- 3- Click Yes to declare the new variable.
- 4- Configure the inputs and outputs of the function block:
 - a. Double-click on the ??? of an input or output.
 - b. Select the variable or enter the name of a new variable according to the following table.
 - c. Click on the green checkmark.

Parameter	Туре	Data type	Parameter configuration	on				
ENABLE	Input	BOOL	Enter <i>true</i> to enable the function, otherwise enter <i>false</i> to disable it.					
SERVERID	Input	UDINT	Enter the Server ID number.					
			IO Drivers					
			📙 🖃 🛄 IEC 61850 Client	Name	Value			
			🗧 📄 🚠 Server 0: STEQ1	Name	STEQ1			
			💼 👘 🗄 (RP) RWONCPUSYI	Server ID	0			
			📕 🗄 📲 (RP) RWONCPUSYI	IP Address	172.16.30.236			
			🖳 🗄 🕎 RightWON	Port	102			
				1				

Document No. RWM002030-MA-en

РАТН	Input	STRING	 Enter the path for the <i>Oper.ctlVal</i> variable of the data object (DO) be selected. To do this: a. In the IO Drivers window, click on a variable. b. Take note of the Path field. 					
			D. Take note of the Path field.					
D:\Workdir\!RightWC	N document	s\!RWCS Tutoriel\I	EC61850\IEC61850Client - IO Drivers *					
E EC 61850) Client							
品 ⊟ 귦 Server	U: Server		Name Server_UB1LDevice_XUBH1_Pos_Uper_ctIVal_CU					
*B	ta of (CB1LDe)	vice/LENUJJ	Variable Type Data Attribute					
	ta of (CB1LDe ^s	vice/LPHDTJJ	Path UBTLDevice/XUBRT/Pos/Uper.ctlVal[UU]					
	CB1LDevice/A	CBR1/Pos/Oper.cti CBR1/Res/Oper.cti	valcoj					
CB1LDevice/XCB1/Pos/Oper.origin.orCat[CO] CB1LDevice/XCBR1/Pos/Oper.origin.orIdent[CO]								
			c. In the program, double-click on the ??? box next to the PATH field.					
			d. Enter the path between single guotes (') and without the server					
			name, for example 'PATH', so that it will be recognized as a					
			character string.					
			e. Then click on $$.					
			Oper_pos IECG1850					
			IEC61850 hTrinSel ENA STA 222					
			CB1LDevice/XCBR1/Pos/Oper.ctMal(CO)					
			TREALB					
			Variables: (all)					
CHECK	Input		Enter the type of verification that an object must carry out before					
CHECK	mput	03111	executing a control operation. See the tonic <i>IEC</i> 61950 Check value					
			definitions in the OFM Library					
			(For further information, refer to the IEC 61850-7-2 standard.)					
IESI	Input	BOOL	Set to <i>true</i> to process the command as a test, otherwise set to <i>false</i> for normal functioning.					
OR CAT	Input	SINT	Enter the Bay-control category for a RightWON IEC 61850 Server:					
011_0711	mput	0	IEC61850_ÉNUM_ORCAŤ_BAY_COŇTROL					
			Specify the category of the initiator that caused a change in value.					
			The list of values is defined in the topic <i>IEC61850 Enums definitions</i>					
			-> ID=ORCAT in the OEM Library.					
			(For further information, consult the IEC 61850-7-3 standard.)					
AUTOSELECT	Input	BOOL	this case, the IEC61850_SELECT function must not be used.					
			• Sat to false to use the direct operate function (DO and SBO					
			models) For the SBO model prior usage of the					
			IEC61850 SELECT function is required					
			recorrect_select runcher is required.					

VALUE	Input	All types	Enter the name of a global variable whose value must be written to the data point (DO) in order to operate (for example $1 \rightarrow$ Close, $0 \rightarrow$ Open). In the example, the <i>Pos</i> DO is to be controlled and is a Boolean data type.
STATUS	Output	UDINT	Enter the name of the variable that indicates the present status of the command. For a list of status indications, see the topic <i>Result for the status output of 61850 master command blocks</i> in the OEM Library.
RESULT	Output	DINT	Enter the name of the output variable for the result of the command to be executed, in accordance with the IEC 61850 control model. For a list of results, see the topic <i>Result for the result output of</i> <i>61850 master command blocks</i> in the OEM Library.

4.4.3. Writing a value to a data attribute

To write a value to a data attribute (DA) that has no control model, carry out the following steps:

1- Add a new program in the **SFC** language. Refer to the topic *Developing an IEC 61131-3 PLC automation program* in the document *RWM000010-MA-en*, *RightWON Configuration Suite Manual*.

Since the IEC61850_WRITE function does not have an **Enable** parameter, it cannot be used in function block format.

2- Select and drag the **IEC61850_WRITE** function block from the list of blocks to the editing window of the program.

D:\W	IWorkdirl/RightWON documents/LRWCS Tutoriel/IEC61850/IEC61850Client - t *										
向		Step	:2 - P1			🗖 🗗 🗖	🖪 🖸 🗙	🍸 Nar	ne T	ype [Dim. Attrib.
τ	1 P1	8	IEC61850_WRITE(<pre>SERVERID(*UDINT*),</pre>	<pre>PATH(*STRING*),</pre>	VALUE (*ANY*)) 🔺	E 🗋	IEC61850		
+	P0	2D							📳 IEC61850_C/	ANCEL (*IEC 61:	850 cancel
10	Act.	IF THEN							1 IEC61850_F1	FDEL (*Request	file to be
T^{-}	2 <u>P1</u>								1 IEC61850_F1	IDIR (*Request	directory lis
⇒ţ	PO								: IEC61850_F1	IGET (*Request	file to be t
tπ		2							1 IEC61850_F1	FQDIR (*Query a	a directory I
									1 IEC61850_F1	[QRES ("Query I	the result o
المربية - ر	-	611							IEC61850_0	PER (*IEC 6185	0 operate
1.1		DL.							IEC61850_SI	ELECT (*IEC 61)	850 select
									:⊡ IEC61850_W	/RITE (*Wirte va	lue to IEC

3- Replace the function parameters according to the following configuration:

Parameter	Туре	Data type	Parameter configuration			
SERVERID	Input	UDINT	Enter the Server ID num IO Drivers E - C 61850 Client Server 0: STEQ1 C RP) RWONCPUSY1 C RP) RWONCPUSY1 RightWON	ber. Name Name Server ID IP Address Port	Value STEQ1 0 172.16.30.236 102	
PATH	Input	STRING	 Enter the path for the <i>Oper.ct/Val</i> variable of the data object (DO) to be selected. To do this: a. In the IO Drivers window, click on a variable. b. Take note of the Path field. 			

Document No. RWM002030-MA-en

D:\Workdir\!F	tightWON docu	iments\!RWCS Tut	oriel\IEC61850\IEC618	50C	lient - 10 Drivers	s*	
E 🖻 🖻	C 61850 Client				Name	Value	
유 브 品	Server 0: Serve	er			Name	Server_CB1LDevice_XCBR1_Pos_Oper_ctMal_CO	
*	"📒 [Data of (CB	31LDevice/LLN0)]			Variable Type	Data Attribute	
, = .	"📒 [Data of (CB	31LDevice/LPHD1)]			Path	CB1LDevice/XCBR1/Pos/Oper.ct/Val[CO]	
<u> </u>	"📒 [Data of (CB	31LDevice/XCBR1)]			IEC Type	BOOL	
	🕞 CB1LDevice/XCBR1/Pos/Oper.ctMal[CO]						
	🗆 🛄 CB1LDe	vice/XCBR1/Pos/0	per.origin.orCat[CO]				
	🗖 🗖 CB1LDe	vice/XCBR1/Pos/0	per.origin.orldent[CO]				
	c. In the program, enter the path between single quotes (') a without the server name, for example 'PATH', so that it will recognized as a character string.						
VALUE	Input	All types	Enter the name of a global variable whose value must be written t the data point (DO) in order to operate (for example $1 \rightarrow$ Close, 0 Open). In the example, the <i>Pos</i> DO is to be controlled and is a Boolean data type.				
Q	Output	BOOL	The output is	trι	<i>le</i> as soon a	as the function is executed.	

In the example below, when the bTrigWr variable has the value 1, the IEC61850_WRITE command is executed once. When bTrigWr returns to 0, the variable returns to its initial state.

	Step:3 - P1	🔲 🗗 🗗 🖬 🗙
1 P1	IEC61850_WRITE(0, 'RWONCPUAUX/LLN0/Mod/Oper.ctlVal[CO]',	sValuetoWr);
	10 · · · · · · · · · · · · · · · · · · ·	
	IF THEM	
2 bTrigWr = 1;		
Act. 3 P1		
	611	
4 bTrigWr = 0;	⊕_B-	
• •		



Configuring the IEC 61850 GOOSE Publisher or Subscriber Protocol

IEC 61850 GOOSE is an advanced version of the UCA GOOSE protocol. The primary difference is that IEC 61850 GOOSE does not have a static number of bits or bit pairs.

A GOOSE message is used to exchange data between several IEDs (Intelligent Electronic Devices) when a change in value occurs.

For further information, refer to the IEC 61850-8 standard and the following Internet sites:

- http://en.wikipedia.org/wiki/GOOSE#Generic_Object_Oriented_Substation_Events_.28G OOSE.29
- http://webstore.iec.ch/webstore/webstore.nsf/mysearchajax?Openform&key=GOOSE&so rting=&start=1&onglet=1

Configuration of the IEC 61850 GOOSE protocol in the RightWON requires the following steps:

- 1- Review the prerequisites for configuring the IEC 61850 protocol
- 2- Add the IEC 61850 GOOSE protocol to the RightWON configuration
- 3- Search the RightWON system information
- 4- Insert a communication port
- 5- Add a GOOSE publisher and/or subscriber
- 6- Create the variables for unassigned objects

The data blocks and variables are configured by default. To see how they are defined:

- 7- Description of data block parameters for the publisher and the subscriber
- 8- Description of variable parameters

5.1. Adding the IEC 61850 GOOSE protocol

The IEC 61850 GOOSE protocol can be added to the RightWON configuration during creation of a new project or by carrying out the following steps:

- 1- Double click on Fieldbus configurations 🏭
- 2- Under the Insert menu, click Insert Configuration... 🖲
- 3- Click on the IEC 61850 GOOSE Subscriber/Publisher protocol.
- 4- Click **OK**.



5.2. Searching the MAC address of an Ethernet port

To be able to configure a port you must know the physical address of the Ethernet port. Follow the steps below:

Note: To connect with the RightWON, refer to the topics on the environment, tools and execution mode in the document *RWM000010-MA-en*, *RightWON Configuration Suite Manual*.

1- Click the **Online** icon in the toolbar to connect to the RightWON.



2- Click on the Tools menu. Then click RightWON System Information ...



3- The **System Information** window permits viewing the physical MAC addresses (**MAC Address**) of the RightWON system. Take note of the address of the Plug-in that has the Ethernet port you wish to use for GOOSE communications (e.g. 00:25:65:00:00:64).

System Information							
Register							
Model	RWU010000						
Version	RWU010000-PR-APP						
Serial Number	1010-10126-2						
Hardware Revision	1						
Plugin [Front-1] Model	RWC0V00xx						
Plugin [Front-1] Serial Number	1000-10000-02						
Plugin [Front-1] Hardware Revision	0						
Plugin [Front-1] MAC Address	00:25:65:00:00:64						
Plugin [Front-2] Model	RWC0G00x						
Plugin [Front-2] Serial Number	0945U15851 ³						

- 4- Close the window.
- 5- Click the **Online** icon in the toolbar to stop execution mode.

File	Edit	View	Insert	Project	Tools	Window	Help									
2		y (🛃 🐰	te fi	×	x -	5	6	tii	쁆	۹6	5	2	§9 B	1	喇
Wor	kspa	ce				IO Drivers	;									Ъ,

5.3. Inserting a communication port

To add a communication port, carry out the following steps:

1- In the IO Drivers window, right-click on IEC 61850 GOOSE Subscriber/Publisher and click Insert Master/Port...



2- Double-click on the **Adapter identification** field, enter the MAC address of the Ethernet Plug-in, then press the **Enter** key. Click **OK**.

(0) 00:25:65:00:00:64		<u>.</u>
Properties	Value	OK,
Index assigned to this adap	0	
Adapter identification	00:25:65:00:00:64	Lancel
		Help

5- Add a GOOSE publisher or subscriber.

5.4. Adding a GOOSE publisher

To add a GOOSE publisher, carry out the following steps:

1- In the IO Drivers area, right-click on the newly created port. Click Add/Update GOOSE publisher Control Block from SCL.



2- Select the SCL file you wish to use, then click Open.

S Open							
€ 0,	🍌 👻 Computer 👻 DATA (D:) 👻 Workdir 👻 Goose	•		- 🐼	Search Goose		2
Organize 🔻	New folder					= -	
	Goose		Name ^	Date mo	dified	Туре	5
	IEC_AND_DNP3 IEC61850		\mu Default	3/23/20	11 9:00 AM	File folder	
	IEC61850_BLOCK		URWBackup	3/23/20	119:11 AM	File folder	
	ISO		WebMI WebMI	3/23/20	11 9:00 AM	File folder	
	kamarak		appli.XML	3/23/20	11 9:11 AM	XML File	
	kema		RW_192.168.1.2.cid	3/4/201	1 2:26 PM	Caller ID Datab	ase
	KEMA_ping_pong						
	Kema_Ping_Pong2						
	KEMMA1						
	mail						
	Meteo						
	Meteo-GSM						
	modbus slave1						
1	MRaymond.Docs						
	MRaymond Mail	•					►
	File name: RW_192.168.1.2.cid			•	IEC document	ts (xml,icd,scl,c	id, 💌
					Open	Canc	el //

- 3- Check the GOOSE Stations checkbox.
- ▲ You cannot select only some of the items in the GOOSE control block. Subscribers that use the same SCL file expect to be able to obtain the data from all objects.



4- To finish, click **OK**.

5.5. Adding a GOOSE subscriber

1- In the **IO Drivers** area of the fieldbus configurator, right-click on the GOOSE port and select **Add/Update GOOSE subscriber Control Block from SCL**.

IO D	rivers			
18	😑 🐼 (0) 00:25:65:00:00:64		A Dama	157
묘	□ Tx => CONTROL/LLN0	P	Properties	
*		×	<u>C</u> lear	
-		X	Cut	
		E.	Copy	
		-13 729	Basta	
		6	r <u>a</u> sie	
è,s	(2,0) CONTROL/GG	幽	<u>F</u> ind	
-	📄 (2,1) CONTROL/GG	¢۹,	Find Next	
∎+	📄 (2,2) CONTROL/GG	-		
	(3,0) CONTROL/GG	Ħ	I <u>n</u> sert Configuration	
	(3,1) CONTROL/GG	뮮	Ingert Master/Port	
	(3,2) CONTROL/GG	*	Ins <u>e</u> rt Slave/Data Block	
		ð	Inse <u>r</u> t Variable	
		_		
	Index assigned t Publisher	∎+	Sor <u>t</u> symbols	
	0	#	Grid	Ctrl+G
			Add/Update GOOSE subscriber Control Block from SCL	
			Add/Update GOOSE publisher Control Block from SCL	
			Create Variable(s) for unassigned Attributes	

2- Select the file that you wish to use, then click **Open**. This file is often the same as the one used by the GOOSE publisher.

5 Open						×
COC 🎍 - Computer - DATA (D:) - Workdir - Goos	se 🕶		- 🐼	Search Goose		2
Organize 🔻 New folder						
beck bobine BPL_test Burn-in canbus commande Demo_Energie demo_valise DemoWebMI DNP3Sv1.4.0 formulaires ge gensetV7 gfibg Goose		Name ^	Date mo 3/23/20 3/23/20 3/23/20 3/23/20 3/4/201	dified 11 9:00 AM 11 9:29 AM 11 9:00 AM 11 9:29 AM 1 2:26 PM	Type File folder File folder File folder XML File Caller ID Dat	tabase
Brown Back In Street St	•	•				Þ
File name: RW_192.168.1.2.cid			•	IEC document	ts (xml,icd,sc	:l,cid, ▼ ncel

3- In our example, we have selected only Indicator 1 and Phase A current measurements.





4- To finish, click OK.



5.6. Creating variables for unassigned objects

To create the variables for one publisher and one subscriber, carry out the following steps:

- 1- In the IO Drivers area, right-click on the GOOSE port (e.g. 00:25:65:00:64).
- 2- Click Create Variable(s) for unassigned Attributes.



3- A window opens to permit creating a variable for the "t" attributes. Click Yes.



4- A window opens to permit creating a variable for the "q" attributes. Click Yes.



5- In the variables area, the newly created variables are displayed in the **Global variables** section.

r	Name	Туре
	🗆 🚮 Global variables	
	{CONTROL/GGI01.Ind1.stVal}	BOOL
	{CONTROL/GGI01.Ind1.q}	UDINT
	{CONTROL/GGI01.Ind1.t}	LREAL
	{CONTROL/GGI01.Ind2.stVal}	BOOL
	{CONTROL/GGI01.Ind2.q}	UDINT
	{CONTROL/GGI01.Ind2.t}	LREAL
	{CONTROL/GGI01.Ind3.stVal}	BOOL
	{CONTROL/GGI01.Ind3.q}	UDINT
	{CONTROL/GGI01.Ind3.t}	LREAL
	{CONTROL/GGI01.Ind5.stVal}	BOOL
	{CONTROL/GGI01.Ind5.q}	UDINT
	{CONTROL/GGI01.Ind5.t}	LREAL
	{CONTROL/GGI01.Ind6.stVal}	BOOL
	{CONTROL/GGI01.Ind6.q}	UDINT
	{CONTROL/GGI01.Ind6.t}	LREAL
	{CONTROL/GGI01.Ind7.stVal}	BOOL
	{CONTROL/GGI01.Ind7.q}	UDINT

6- Repeat from step 1 for all publishers and all subscribers.

5.7. Description of data block parameters

In the **IO Drivers** area, click on the publisher **(Tx)** or subscriber **(Rx)** data block to view the list of parameters.

Note: The values of these parameters come from the SCL file.

- Index assigned to this GOOSE control block: The index number of the GOOSE block. Two data blocks cannot have the same index number.
- **Publisher:** If the block is a publisher, the box is checked. If the block is a subscriber, the box is unchecked.
- **GOOSE Control block reference:** Name and location of the control block in the object model.
- **APPID:** Application ID. This number must be the same on a publisher and its subscribers.
- VLAN priority: Specifies the priority of packets over the network.
- DataSet: Name and location of the dataset in the object model.
- NbDSEntries: Number of data objects in the subscriber block.

Name	Value
Index assigned to this GOOSE control block	0
Publisher	✓
GOOSE Control block reference	CONTROL/LLN0\$G0\$cbGooseST
APPID (Rx.ignored if -1)	12288
GOOSE Multicast address	01:0C:CD:01:00:00
VLAN priority	4
DatSet (Rx:ignored if empty)	CONTROL/LLN0\$dsGooseST
GoID (Rx:ignored if empty)	C264_1_ST
ConfRev (Rx:ignored if -1)	1
NbDSEntries (Rx:ignored if -1)	0
Additional wait time after TAL (ms)	0
Additional wait time after TAL (% of last rovd TAL)	0
publish TAL Sequence (ms)	300,600,1200,2400,4800,9600,16400,20000
publish Tx Delay Sequence (ms)	290,590,1190,2390,4790,9590,16390,19990

5.8. Description of variable parameters

The variables created for unassigned attributes have been associated with publisher and subscriber data. Click on an object in a data block to view the associated parameters in the table on the right.

Note: The values of these parameters come from the SCL file.

- Symbol: Name and location of the object in the object model.
- Attribute Type: The type of attribute.
- Attribute Data Location in Dataset: The location of the attribute in the object model.
- Publish on Change:
 - a. For a **publisher (Tx)** the box is checked, so that a GOOSE message will be sent when the value of the object changes.

10) Drivers *		
E	目 📮 🖳 IEC 61850 GOOSE Subscriber/Publisher	Name	Value
1	i interference (0) 00:25:36:00:00:64	Symbol	{CONTROL/GGI01.Ind1.stVal}
4	📙 🗖 Tx => CONTROL/LLN0\$GO\$cbGooseST	Attribute Type	Data Content
	(0,0) CONTROL/GGI01.Ind1.stVal => {CONTROL/GGI01.Ind1.stVal}	Attribute Name, for reference only	CONTROL/GGI01.Ind1.stVal
2	☐ (0,1) CONTROL/GGI01.Ind1.q => {CONTROL/GGI01.Ind1.q}	Attribute Data Location in Dataset, Ex.: 3 or 2,1,1	0,0
E	😝 👘 (0,2) CONTROL/GGIO1.Ind1.t => (CONTROL/GGIO1.Ind1.t)	Attribute MMS Type	BOOLEAN
	(1,0) CONTROL/GGI01.Ind2.stVal => {CONTROL/GGI01.Ind2.stVal}	Attribute MMS Type Length	0
-	(1,1) CONTROL/GGI01.Ind2.q => {CONTROL/GGI01.Ind2.q}	Attribute MMS Type Length is Fixed	
ġ	(1,2) CONTROL/GGI01.Ind2.t => (CONTROL/GGI01.Ind2.t)	Binding Mode	Normal
	(2,0) CONTROL/GGI01.Ind3.stVal => {CONTROL/GGI01.Ind3.stVal}	Publish on Change	✓
	(2,1) CONTROL/GGI01.Ind3.q => {CONTROL/GGI01.Ind3.q}		
	(2,2) CONTROL/GGI01.Ind3.t => (CONTROL/GGI01.Ind3.t)		
	(3,0) CONTROL/GGIO1.Ind5.stVal => {CONTROL/GGIO1.Ind5.stVal}		
	(3,1) CONTROL/GGI01.Ind5.q => {CONTROL/GGI01.Ind5.q}		

b. For a **subscriber (Rx)** the box is unchecked, since a subscriber cannot send a GOOSE message. The subscriber receives its objects from the publisher.

EC 61850 GOOSE Subscriber/Publisher	Name	Value
	Symbol	{TEMPLATECONTROL/LLN0.cbGooseST[CONTROL/GGI01.ind1.stVal}
Rx <= TEMPLATECONTROL/LLN0\$G0\$cbGooseST	Attribute Type	Data Content
(0,0) CONTROL/GGI01.Ind1.stVal => {TEMPLATECONTROL/LLN0.cbGoc	Attribute Name, for reference only	CONTROL/GGI01.Ind1.stVal
(0,1) CONTROL/GGI01.Ind1.q => {TEMPLATECONTROL/LLN0.cbGoose9	Attribute Data Location in Dataset, Ex.: 3 or 2	0,0
(0,2) CONTROL/GGI01.Ind1.t => {TEMPLATECONTROL/LLN0.cbGooseS	Attribute MMS Type	BOOLEAN
🛅 (7,1,0,0,0) MEASUREMENT/msMMXU1.A.phsA.cVal.mag.f => {TEMPLATE	Attribute MMS Type Length	0
(7,1,1) MEASUREMENT/rmsMMXU1.A.phsA.q => {TEMPLATECONTROL/	Attribute MMS Type Length is Fixed	
(7,1,2) MEASUREMENT/rmsMMXU1.A.phsA.t => {TEMPLATECONTROL/L	Binding Mode	Normal
🗄 🕎 RightWON	Publish on Change	



Appendix: Accessing the OEM Library

Definitions of the codes for IEC 61850 global variables are provided in the OEM Library. To access the Global Variable definitions file, carry out the following steps:

- 1- Double-click on a program in the Workspace.
- 2- In the Variables area, click on the **Define** tab.
- 3- Double-click on Library Defines (OEM).





Vizimax Inc. 2284 de la Province Longueuil, Québec Canada J4G 1G1 Tel. (450) 679-0003 Fax: (450) 679-9051 Sales@vizimax.com www.vizimax.com